

Dobot CR Series User Guide



Issue: V1.2 Date: 2023-06-08

Shenzhen Yuejiang Technology Co.,Ltd. | China



Copyright © Shenzhen Yuejiang Technology Co., Ltd. 2023. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without the prior written consent of Yuejiang Technology Co., Ltd.

Disclaimer

To the maximum extent permitted by applicable law, the products described (including its hardware, software, and firmware, etc.) in this document are provided **AS IS**, which may have flaws, errors or faults. Dobot makes no warranties of any kind, express or implied, including but not limited to, merchantability, satisfaction of quality, fitness for a particular purpose and non-infringement of third party rights. In no event will Dobot be liable for any special, incidental, consequential or indirect damages resulting from the use of our products and documents.

Before using our product, please thoroughly read and understand the contents of this document and related technical documents that are published online, to ensure that the robot is used on the premise of fully understanding the robot and related knowledge. Please use this document with technical guidance from professionals. Even if follow this document or any other related instructions, damages or losses will be happening in the using process. Dobot shall not be considered as a guarantee regarding all security information contained in this document.

The user has the responsibility to make sure of following the relevant practical laws and regulations of the country, in order that there is no significant danger in the use of the robot.

Shenzhen Yuejiang Technology Co., Ltd.

Address: Room 1003, Building 2, Chongwen Garden, Nanshan iPark, Liuxian Blvd, Nanshan

District, Shenzhen, Guangdong Province, China

Website: www.dobot-robots.com



Preface

Scope of Application

Robot arm:

- DOBOT CR3
- DOBOT CR5
- DOBOT CR7
- DOBOT CR10
- DOBOT CR12
- DOBOT CR16

You can find the model of robot arm on the right-top corner of the nameplate on the robot base. The figure below takes CR5 as an example.





Controller:

DOBOT CC162

You can find the model of controller on the right-top corner of the nameplate.



型号/MODEL	DT-CR-CC162-00I	
重量/WEIGHT	12 kg	
防护等级/ENCLOSURE TYPE	IP20	
最大功率/MAXIMUM POWER	650 W	
输入电压/INPUT VOLTAGE	1PHASE, AC 100V~240V	
输入频率/INPUT FREQUENCY	50/60 Hz	
短路电流额定值/SCCR	5 kA	





Purpose

This document introduces the functions, technical specifications and installation procedure of Dobot CR series robots, which is convenient for users to understand and use the robot.

Intended Audience

This document is intended for:

- Customer
- Sales Engineer
- Installation and Commissioning Engineer
- Technical Support Engineer

Change History

Date	Change Description	
2023/06/08	Add CR7 and CR12 load curves	
2023/04/27	Modify CR7 base installation dimensions	
2022/12/05	Integrate CR3, CR5, CR7, CR10, CR12, CR16 hardware guides	

Symbol Conventions

The symbols that may be found in this document are defined as follows.

Symbol	Description		
≜ DANGER	Indicates a hazard with a high level of risk which, if not avoided, could result in death or serious injury		
1 WARNING	Indicates a hazard with a medium level or low level of risk which, if not avoided, could result in minor or moderate injury, robot damage		
⚠NOTICE	Indicates a potentially hazardous situation which, if not avoided, can result in equipment damage, data loss, or unanticipated result		
MNOTE	Provides additional information to emphasize or supplement important points in the main text		



Contents

1. 8	Safet	y		1
		•	ty	
		1.1.1	Validity and Responsibility	1
		1.1.2	Limitation of Liability	1
		1.1.3	Intended Use	1
	1.2	Safety	warning signs	2
	1.3	Genera	al safety	2
	1.4	Person	al safety	6
	1.5	Emerge	ency	6
		1.5.1	Emergency stop switch	6
		1.5.2	Emergency recovery	6
		1.5.3	Forced joint movement	7
2. 7	Γran	sporta	tion	8
3. I	Prod	uct Int	roduction	9
	3.1	Overvi	iew	9
	3.2	Robot	arm	10
		3.2.1	Composition	10
		3.2.2	End buttons and indicator lights	11
	3.3	Contro	oller	13
	3.4	Operat	tion terminal	14
4. I	Prod	uct Fea	atures	15
	4.1	Coordi	inate system	15
		4.1.1	Joint coordinate system	15
		4.1.2	User coordinate system	15
		4.1.3	Tool coordinate system	16
	4.2	Home 1	posture	16
	4.3	Singula	arity Point	17
		4.3.1	Shoulder singularity	17
		4.3.2	Elbow singularity	18
		4.3.3	Wrist singularity	18
	4.4	Brakin	g time and braking distance	19
5. N	Mech	nanical	Specifications	20
	5.1	CR3 m	nechanical specifications	20
		5.1.1	CR3 dimensions and working space	20
		5.1.2	CR3 base installation dimensions	20
		5.1.3	CR3 flange dimensions	21
		5.1.4	CR3 load curve	21
	5.2	CR5 m	nechanical specifications	22
		5.2.1	CR5 dimensions and working space	22
		5.2.2	CR5 base installation dimensions	23
		5.2.3	CR5 flange dimensions	24
		5.2.4	CR5 load curve	24
	Issue	· V1 2 (20	023-06-08) User Guide Convright © Yueijang Technol	ogy Co. I td



	5.3 CR7 dimensions			25
		5.3.1	CR7 product dimensions	25
		5.3.2	CR7 base	26
		5.3.3	CR7 end flange	27
		5.3.4	CR7 load curve	28
	5.4	CR10 1	mechanical specifications	28
		5.4.1	CR10 dimensions and working range	28
		5.4.2	CR10 base installation dimensions	29
		5.4.3	CR10 end flange dimensions	30
		5.4.4	CR10 load curve	31
	5.5	CR12 1	mechanical specifications	31
		5.5.1	CR12 dimensions and working range	31
		5.5.2	CR12 base installation dimensions	32
		5.5.3	CR12 end flange dimensions	33
		5.5.4	CR12 load curve	34
	5.6	CR16 1	mechanical specifications	34
		5.6.1	CR16 dimensions and working space	34
		5.6.2	CR16 base installation dimensions	35
		5.6.3	CR16 end flange dimensions	36
		5.6.4	CR16 load curve	37
	5.7	Contro	ller dimensions	37
6. I	Elect	rical F	eatures	39
	6.1	Contro	ller interface	39
		6.1.1	Overview	39
		6.1.2	General I/O interface panel	40
		6.1.3	Digital I/O interface	
		6.1.4	Analog I/O interface	44
		6.1.5	Encoder I/O interface	45
		6.1.6	Safety I/O interface	46
	6.2	Robot	interface	49
		6.2.1	Heavy-duty interface	50
		6.2.2	Tool I/O interface	50
7. I	nsta	llation	and Use	54
	7.1		ation environment	
	7.2	Unpacl	king	54
	7.3	Robot	installation	55
		7.3.1	Robot arm installation	55
		7.3.2	Controller installation	55
		7.3.3	End tool installation	56
	7.4	Wiring	Ţ	56
		•	ging	
8. I	Main		ce	
	8.1	•	instructions	
	8.2	Robot	maintenance	59
	-	111 0 (0)	1)23-06-08) User Guide Convright © Vueijang Technology C	



9. Certification	1	61
10. Warranty.		71
•	warranty	
10.2 Disclair	ner	71
Appendix Tech	ınical Specifications	72
Appendix A	Robot technical specifications	72
Appendix B	Controller technical specifications	76
Appendix C	I/O simple circuit and specifications	78



1. Safety

1.1 Liability

1.1.1 Validity and Responsibility

The information in this document does not cover designing, installing and operating a complete robot system, nor does it cover all peripheral equipment that can affect the safety of the complete system. The complete system must be designed and installed in accordance with the safety requirements set forth in the standards and regulations of the country where the robot is installed.

The integrators of Dobot are responsible for ensuring that the applicable safety laws and regulations in the country concerned are observed and that any significant hazards in the complete robot application are eliminated. This includes, but is not limited to:

- Performing a risk assessment for the complete robot system.
- · Adding safety machines and mechanisms based on the risk assessment.
- Setting up the appropriate safety settings in the software.
- Ensuring that the user will not modify any safety measures.
- Validating that the total robot system is designed and installed correctly.
- Specifying instructions for use.
- Marking relevant signs and contact information of the integrators on the robot.
- · Archiving relevant technical files.

1.1.2 Limitation of Liability

Any safety information provided in this document should not be construed as a warranty, by Dobot. The robot may cause injury or damage even if all safety instructions are observed.

1.1.3 Intended Use

Dobot CR series robots are industrial robots only for general industrial use, such as processing or delivering products or parts through end tools.

Dobot CR series robots are equipped with special safety mechanisms including collision detection. These mechanisms are purposely designed for human-robot collaborative operation, but only intended for non-hazardous applications after risk assessment, where tools, commodities, environments and other machines have been demonstrated to be incapable of significant risk through application-specific risk assessments.

Any use or application deviating from intended use is deemed to be impermissible misuse, including, but is not limited to:

- Use in potentially explosive environments.
- Use in life critical applications.
- Use before performing a risk assessment.
- Use over-stated specifications.



• Use as a climbing aid.

1.2 Safety warning signs

The following safety warning signs may appear in this document, and their meanings are described as follows. The same safety warning signs are also used in the products.

Sign	Description
⚠ DANGER	Indicates a high degree of potential danger, which, if not avoided, will result in death or serious injury.
May cause dangerous power consumption soon, which, if not avoided, we personal injury or serious damage to the equipment.	
	May cause dangerous hot surfaces, which, if touched, may cause personal injury.
or	
高温小心烫伤 Careful scald at high temperature	
≜ WARNING	Indicates a moderate or low potential hazard, which, if not avoided, may cause minor personal injury and damage to the equipment.
ATTENTION	Indicates a potential risk, which, if ignored, may result in damage to the robot arm, loss of data or unpredictable results
⚠NOTICE	A situation that, if not avoided, can cause personal injury or damage to the equipment.
	For items marked with such signs, depending on the specific situation, there is sometimes a possibility of significant consequences

1.3 General safety

Follow the safety instructions below when starting and using the robot for the first time.



- The robot system is electrical equipment. Non-professional technicians should not modify the circuit, otherwise, it may cause damage to devices or personal injury.
- Comply with the local laws and regulations when operating the robot. The security
 precautions in this document are only supplemental to the local laws and
 regulations.
- Use the robot in the specified environment scope. Exceeding the specifications or load conditions will shorten the service life of the robot, even damage it.

Issue V1.2 (2023-06-08)

User Guide

Copyright © Yuejiang Technology Co., Ltd.



- Ensure that the robot is operated under the security conditions and there is no harmful object around the robot.
- Turning on or off the power continually may result in degraded performance of the main circuit components inside the controller. If turning on or off the power continually is required, please keep the frequency less than once per minute.

MHOT

- The robot and the controller will generate heat during operation. Please do not operate or touch the robot when the robot is working or has just stopped working.
- Turn off the power and wait an hour for the robot to cool down.
- Do not put your fingers to where the control cabinet gets hot.

NOTICE

- The personnel responsible for installation, operation and maintenance of equipment must first receive strict training, understand various safety precautions, and master correct operation and maintenance methods before they can operate and maintain equipment.
- Personnel without professional training shall not disassemble and repair the
 equipment without authorization. If the device fails, please contact Dobot technical
 support engineer in time.
- Be sure to carry out daily inspections and regular maintenance, and replace faulty components in time to ensure the safe operation of the equipment.
- If the equipment is scrapped, please comply with relevant laws to properly handle industrial waste and protect the environment.
- In order to prevent personnel from accidentally entering the working space of the robot arm, be sure to set up safety fence to prevent personnel from entering the hazardous area.
- Before operating the robot, make sure that no one is inside the safety fence. When operating the robot, be sure to operate outside the safety fence.
- Do not expose the robot to permanent magnetic fields all the time. Strong magnetic fields can cause damage to the robot.
- Dobot assumes no responsibility for robot damage or personal injury caused by failure to follow product instructions or other improper operations.
- Use appropriate and reliable lifting equipment during handling operations such as
 lifting rings and bridge crane. According to the relevant regulations of various
 countries, it must be carried out by personnel with operating qualification
 certificates or personnel authorized by the company.
- Make sure that there are no obstacles within 2 meters of the robot during



transportation. Relevant personnel should stay away from the suspended robot.

- Dobot is not responsible for any damage caused during the transportation and handling of equipment.
- Make sure that the robot is in the packing posture before packaging, and the brakes on each axis are normal.
- Make sure that there are no obstacles around the packing area, so that the staff can leave in a timely manner in case of an emergency.
- When the robot is transported, the packaging needs to be fixed to ensure that the robot is stable.
- After removing the outer packaging, make sure that the robot maintains the original packing posture and the brakes of each axis are normal.
- During the commissioning process, make sure that no relevant personnel and equipment (include computer used for debugging) stay in the dangerous area of the machine.
- If necessary, wear corresponding safety protective equipment, such as safety helmets, safety shoes (with non-slip soles), face shields, protective glasses and gloves. Inappropriate clothing may cause personal injury.
- In order to prevent personnel from entering the working space of the robot arm by mistake, please set up safety barriers to prevent personnel from entering the hazardous area.
- Do not enter the working space of the manipulator at will during operating the robot, otherwise cause injury to the robot or yourself.
- The personnel responsible for installation, operation, and maintenance of the
 equipment must first undergo strict training, understand various safety precautions,
 and master the correct operation and maintenance methods before operating and
 maintaining the equipment.
- When an abnormality occurs in the mechanical arm, it is necessary to ensure that the machine is stopped and then checked.
- After the commissioning of the operator is completed, the test needs to be performed
 in the Manual mode first, and then it is automatically run after it is confirmed to be
 correct.
- If the controller needs to be restarted due to power failure, when restarting, the robot must be manually returned to the initial position of the automatic operation program before restarting the automatic operation.
- Before maintenance and wiring work, the power supply must be cut off, and the sign No power supply must be put on. Otherwise, electric shock and personal injury may result.



- Please observe the ESD regulations when disassembling the robot or controller.
- Avoid dismantling the power supply system in the controller. After the controller is turned off, its power supply system may still have high voltage for several hours.
- Please contact our technical support staff for the disassembly and repair of the robot.
- Maintenance and repair work must be carried out by designated personnel, otherwise electric shock and personal injury may result.
- If the brake is manually released, the robot may move because of the action of gravity. So, when manually releasing the brake, please ensure that the robot body and the tools or workpieces installed on the robot are effectively supported.
- In order to prevent electric shock, when replacing parts, please turn off the circuit breaker in advance and cut off the main power before proceeding.
- Turn off the main power supply for 5 minutes before replacing parts.
- The replacement operation must be performed by the specified operator.
- The robot is designed and tested according to the group I class A engineering medical robot standard. In order to reduce the radio interference in in light industry or family environment, please take protective measures.
- It is prohibited to operate the robot in strong radiation environment (such as RF source without shielding), otherwise, it could interference robot work.

MWARNING

- Before the operation, please wear protective clothing, such as antistatic uniform, protective gloves, and protective shoes.
- It is prohibited to modify or remove the nameplates, instructions, icons and marks on the robot and the related equipment.
- Before operating the equipment, please find and be familiar with the operation method of the emergency stop function to ensure that the robot arm can be stopped urgently in the case of sudden stress. The emergency stop function is Stop Category
 1.
- Be careful when carrying or installing the robot. Please follow the instructions on the packing box to put down the robot gently and place it correctly in the direction of the arrow.
- Please use the matched cables when connecting a robot to internal or external equipment for personal security and equipment protection.
- Please ensure that the robot and tools are installed correctly.
- Please ensure that the robot has enough space to move freely.



- If the robot is damaged, do not continue to use it.
- Any impact will release a lot of kinetic energy, which is much higher than that under high speed and high load.

1.4 Personal safety

When operating the robot system, please strictly follow the general precautions listed below to ensure the personal safety of the operator.

MWARNING

- Please comply with local laws or regulations with regard to the maximum weight one person is permitted to carry.
- Do not touch the terminal blocks or disassemble the equipment with the power ON.
 Otherwise, it may result in an electric shock.
- Please confirm that the equipment is well grounded, otherwise it will endanger personal safety.
- Do not touch the terminal blocks or remove the interval circuit components within 10 minutes after the power is shut off, so as to avoid an electric shock since there is residual capacitance inside the controller.
- Even if the power switch of the controller is already in the OFF status, touching the
 terminal blocks or removing the interval circuit components is not allowed, so as to
 avoid an electric shock since there is residual capacitance inside the controller.
- When working with robots, do not wear loose clothing or jewelry. When operating the robot, make sure that you have bundle your hair behind your head.
- If the robot appears to have stopped during the operation of the equipment, it may be because the robot is waiting for the start signal and is in the state of being about to move. In this case, the robot should also be considered to be in motion. Do not approach the robot.

1.5 **Emergency**

1.5.1 Emergency stop switch

After you press the emergency stop switch in emergencies, the robot will immediately stop all motions and be locked.

The emergency stop switch is not a safeguard. It is a complimentary protective measure and are not intended to prevent injury.

1.5.2 Emergency recovery



The emergency stop switch will be locked after you press it. To unlock the switch, you need to rotate the switch according to the mark on the switch.



Please operate the robot to recover from the emergency only after the danger of the robot system is completely removed.

1.5.3 Forced joint movement

In the unlikely event of an emergency, you may need to move the robot joint/s when the robot power is either impossible or unwanted. In this case, you must push or pull the robot arm hard to move the joint.



Moving the locked joints forcefully may cause joint damage. Please operate only in emergencies.



2. Transportation

You need to transport the robot in its packaging posture (set in the control software in reference to the user guide of the control software for details), and use the original packaging for transportation.

During transportation, ensure that the robot arm is stable and fixed by corresponding measures.

During transportation and long-term storage, ensure that the ambient temperature ranges from -20 °C to +55 °C, and the ambient humidity is no more than 95% without condensation.

When moving the robot from its packaging to the installation space, hold the robot arm in place until all mounting bolts are securely tightened at the base of the robot.

After transportation, store the original package in a dry place for repacking and transporting it in the future.



- Ensure that the operator is not unduly stressed on their back or other body parts
 when lifting the equipment, and use appropriate lifting equipment if necessary.
- Dobot shall not be held responsible for any damage caused by transportation of the equipment.
- Be sure to follow all installation instructions when installing the robot.



3. Product Introduction

3.1 Overview




Figure 3.1 Robot overview

The main components of the robot system include:

- **CR robot:** six-axis robot arm, main moving parts.
- Controller: core computing and electrical components.
- **Emergency stop switch:** connected to the controller to realize the emergency stop function.
- **Wireless receiver:** plugged into the controller, so that the operating terminal can be connected to and control the robot via WiFi.
- **Heavy-duty cable**: connect the robot arm to the controller.

In addition, the system includes an **operating terminal** (tablet or PC) for installing the robot control software.





Figure 3.2 Operation terminal

3.2 Robot arm

3.2.1 Composition

CR series robot arm includes 6 rotating motion joints, and two connecting rods (upper arm and forearm), as shown in Figure 3.3 (taking CR5 as an example). The robot arm is equipped with a heavy-duty interface on its base, buttons and indicator light on its end, and an aerial plug on its end flange side.






Figure 3.3 CR robot

3.2.2 End buttons and indicator lights

CR series robot arm is equipped with several buttons and indicator light on its end, as shown in Figure 3.4.





Trajectory playback button Trajectory recording button Enabling button

Figure 3.4 End buttons and indicator light

The definition of the indicator light is shown in Table 3.1.

Table 3.1 Definition of indicator lights

Color	Status	Definition	
Blue light	Steady on	The robot arm has been started but not enabled	
	Flash	Hand-guiding status (or the robot arm is starting/the robot arm and controller failed to be connected)	
Green light	Steady on	The robot arm is enabled (not run projects)	
	Flash	Automatic running (project is running)	
Yellow light	Steady on	Trajectory recording	
	Flash	Trajectory playback	
Red light	Steady on	System error	

The functions of the end button are shown below:

- Hand-guiding button: When the robot arm is in the enabled status (the indicator light is green and steady on), long press the button for 3 seconds and then release it, and the robot arm will enter the hand-guiding status (the indicator light flashes blue). After dragging the robot arm to the teaching point, press the end button again for a short time, and the robot arm will exit the hand-guiding status (the indicator light turns to green and steady on).
- End control button: Short-press the button to control the end tool. For specific functions, you need to configure in "Dobot+" page of the control software.
- Enabling button: When the robot arm is powered on and in the disabled status (the indicator light is blue and steady on), long press the button for 3 seconds and then release it, and the robot arm will enter the enabled status (the indicator light flashes blue). The Issue V1.2 (2023-06-08)

 User Guide Copyright © Yuejiang Technology Co., Ltd.



- indicator light turns green after the robot arm is enabled successfully. Then long press the button for 6 seconds and release it, and the robot arm starts being disabled (the indicator light flashes green). The indicator light turns blue after the robot arm is disabled.
- Trajectory recording button: When the robot arm is in the enabled status (the indicator light is green and steady on), long press the button for 3 seconds and release it, and the robot arm will enter the trajectory recording status (the indicator light is yellow and steady on). After recording the trajectory, short-press the button again, and the robot arm will exit the trajectory recording status (the indicator light turns to green and steady on).
- Trajectory playback button: When the robot arm is in the enabled status (the indicator light is green and steady on), long press the button for 3 seconds and release it, and the robot arm enters the trajectory playback status (the indicator light flashes yellow) to play back the last recorded trajectory. Then short-press the button again, and the robot arm will exit the trajectory playback status (the indicator light turns to green and steady on).

3.3 Controller

CR series robot arms need to be used with a controller. Figure 3.5 shows the appearance of the controller. For details on its electrical interfaces, see *6 Electrical Features*.



Figure 3.5 Controller

After connecting the power supply and the robot arm, short press the power switch to turn on the controller and the robot arm. Then the blue light starts to flash. When the blue light is steady on, it indicates the controller is started successfully.

After the controller is started, long press the power switch for more than 3s and release it, then the controller and the robot arm will be powered off. When the blue light is off, it indicates the controller is powered off.

Issue V1.2 (2023-06-08)

User Guide

Copyright © Yuejiang Technology Co., Ltd.



Above the general IO interface on the back of the controller are three indicator lights (green, yellow and red), which indicate the status of the main control board of the controller.

- Green light: power indicator, which is steady on after the power is turned on.
- Yellow light: communication indicator, which flashes when there is communication within the internal bus of the controller.
- Red light: running indicator, which flashes when the controller is running. When the main
 control board of the controller works normally, the controller will start running after being
 powered on, that is, the red light should be flashing at the same time when the green light
 is on.

3.4 Operation terminal

CR series robot arms support control through PC and App, as shown in Table 3.2. If you need to use WiFi for control, you need to plug the WiFi module into the controller.

Table 3.2 Operation terminal parameters

Terminal type	PC	Tablet (Android)	iPad
Operation system	Windows7/10/11	Android 10 and above	iOS 10 and above
Control software	DobotStudio Pro	Dobot CRStudio	Dobot CRStudio
Minimum	CPU: Intel Core i3	CPU: 4-core	Storage space: 32G
configuration	Memory: 4GB	Running memory: 2G	
	Storage space: 256GB	Storage space: 32G	
Communication mode	LAN/WiFi	WiFi	WiFi

When purchasing CR series robot arms, you can ask for matching Android tablets; or use self-prepared operating terminal which meets the minimum configuration in Table 3.2. It is recommended to use Huawei C5 tablet.



4. Product Features

4.1 Coordinate system

4.1.1 Joint coordinate system

The joint coordinate system is determined based on all motion joints. All joints are rotating joints, as shown in Figure 4.1.




Figure 4.1 Joint coordinate system

4.1.2 User coordinate system

The user coordinate system is a movable coordinate system which is used for representing equipment like fixtures, workbenches. The origin and the orientations of axes can be defined based on the site requirements to measure point data within the workspace and arrange tasks conveniently. The default user coordinate system is determined based on the center point at the robot base, as shown in Figure 4.2.






Figure 4.2 User coordinate system

4.1.3 Tool coordinate system

The tool coordinate system defines the tool center point (TCP) and tool posture, of which the origin and orientations vary with the position and angle of the workpiece at the end of robot. The default tool coordinate system is determined based on the center point of the end flange, as shown in Figure 4.3.




Figure 4.3 Tool coordinate system

4.2 Home posture

When the robot arm is in the vertical state shown in Figure 4.1, the angle of all joints is 0 degrees. This posture is called the home posture. The home-point stickers as shown in Figure 4.4 are attached to each joint of the robot arm. When the joint is 0 degree, the stickers on both sides of the joint will be aligned.





Figure 4.4 Home point sticker

If the home point of the robot arm changes due to the replacement of the transmission parts or the collision, you can move the robot arm to a state where all the home-point stickers of each joint are aligned, and then calibrate the home-point through the control software.

4.3 Singularity Point

4.3.1 Shoulder singularity

When the intersection of the J5 axis and the J6 axis of the robot arm is located in the plane formed by the J1 axis and the J2 axis, it will lead to singularity, as shown in Figure 4.5.






Figure 4.5 Shoulder singularity

4.3.2 Elbow singularity

When the upper arm and forearm are in the same line, it will lead to singularity, as shown in Figure 4.6.




Figure 4.6 Elbow singularity

4.3.3 Wrist singularity



When the J4 axis and J6 axis are parallel, it will lead to singularity, as shown in Figure 4.7.



Figure 4.7 Wrist singularity

4.4 Braking time and braking distance

When the J1~J3 axes triggers an emergency stop at 100% speed, maximum load and maximum arm span, the braking time and braking distance of each joint are shown in the table below.

For the J1 axis, the test is performed by moving horizontally, namely, the rotation axis is perpendicular to the ground.

For the J2 and J3 axis tests, the robot follows a vertical trajectory, namely, the rotation axis is parallel to the ground, and triggers an emergency stop when the robot moves downward.

Table 4.1 only includes the data of some models for your reference.

Table 4.1 Braking time and Braking distance

Axis	Braking time/Braking distance			
	CR3	CR5	CR10	CR16
J1	122ms / 84.89mm	141ms / 179.39mm	114ms / 135.51mm	126ms / 144.58mm
J2	165ms / 83.97mm	161ms / 158.19mm	127ms / 177.88mm	127ms / 136.02mm
Ј3	98ms / 92.72mm	100ms / 180.99mm	126ms / 229.43mm	141ms / 199.45mm



5. Mechanical Specifications

All dimensions in this chapter are in millimeters (mm).

5.1 CR3 mechanical specifications

5.1.1 CR3 dimensions and working space

When selecting the installation position for the robot, you must consider the cylindrical space directly over and under the robot, and avoid moving the tool to the cylindrical space as much as possible. Because this will cause the joints to rotate too fast while the tool moves slowly, resulting in low working efficiency of the robot and difficult risk assessment.




Figure 5.1 CR3 dimensions and working space

5.1.2 CR3 base installation dimensions






Figure 5.2 CR3 base installation dimensions

5.1.3 CR3 flange dimensions

The end flanges of CR series robot arms are all in the same size. The flange design conforms to ISO 9409-1.




Figure 5.3 End flange dimensions

5.1.4 CR3 load curve

Issue V1.2 (2023-06-08)

User Guide

Copyright © Yuejiang Technology Co., Ltd.



In the load curve, the coordinate origin is the center of the end flange, and X, Y represent the distance between the gravity center of load and the robot flange in X and Y directions. According to $r = \sqrt{X^2 + Y^2}$, the value **r** corresponds to the vertical coordinate X, Y[cm] of the load curve, and the abscissa Z[cm] represents the distance from the gravity center of the load to the robot flange in Z direction. You can determine the working condition of the robot according to the statistical results. For example, if the load is 2.8kg, X = 6cm, Y = 8cm, Z = 5cm, and you can get r = 10cm. The steps for judgement are as follows:

- According to $r = \sqrt{X^2 + Y^2}$, calculate r = 10cm.
- Select the corresponding curve according to the weight of the load. As the load is 2.8kg, you need to find the curve of 3kg correspondingly.
- Determine a point according to the r and Z coordinates, and compare the positional relationship between the point and the 3kg curve to judge the working condition. If the point is below the curve, the model is proper, otherwise you need to select other models.




Figure 5.4 CR3 load curve

5.2 CR5 mechanical specifications

5.2.1 CR5 dimensions and working space

When selecting the installation position for the robot, you must consider the cylindrical space directly over and under the robot, and avoid moving the tool to the cylindrical space as much as possible. Because this will cause the joints to rotate too fast while the tool moves slowly, resulting in low working efficiency of the robot and difficult risk assessment.






Figure 5.5 CR5 dimensions and working space

5.2.2 CR5 base installation dimensions






Figure 5.6 CR5 base installation dimensions

5.2.3 CR5 flange dimensions

The end flanges of CR series robot arms are all in the same size. The flange design conforms to ISO 9409-1.




Figure 5.7 End flange dimensions

5.2.4 CR5 load curve

In the load curve, the coordinate origin is the center of the end flange, and X, Y represent the

Issue V1.2 (2023-06-08)

User Guide

Copyright © Yuejiang Technology Co., Ltd.



distance between the gravity center of load and the robot flange in X and Y directions. According to $r = \sqrt{X^2 + Y^2}$, the value **r** corresponds to the vertical coordinate X, Y[cm] of the load curve, and the abscissa Z[cm] represents the distance from the gravity center of the load to the robot flange in Z direction. You can determine the working condition of the robot according to the statistical results. For example, if the load is 2.8kg, X = 6cm, Y = 8cm, Z = 5cm, and you can get r = 10cm. The steps for judgement are as follows:

- According to $r = \sqrt{X^2 + Y^2}$, calculate r = 10cm.
- Select the corresponding curve according to the weight of the load. As the load is 2.8kg, you need to find the curve of 3kg correspondingly.
- Determine a point according to the r and Z coordinates, and compare the positional relationship between the point and the 3kg curve to judge the working condition. If the point is below the curve, the model is proper, otherwise you need to select other models.




Figure 5.8 CR5 load curve

5.3 CR7 dimensions

5.3.1 CR7 product dimensions

When selecting the installation position for the robot, you must consider the cylindrical space directly over and under the robot, and avoid moving the tool to the cylindrical space as much as possible. Because this will cause the joints to rotate too fast while the tool moves slowly, resulting in low working efficiency of the robot and difficult risk assessment.




Figure 5.9 CR7 dimensions and working space

5.3.2 **CR7 base**






Figure 5.10 CR7 base installation dimensions

5.3.3 CR7 end flange

The end flanges of CR series robot arms are all in the same size. The flange design conforms to ISO 9409-1.




Figure 5.11 End flange dimensions



5.3.4 CR7 load curve

In the load curve, the coordinate origin is the center of the end flange, and X, Y represent the distance between the gravity center of load and the robot flange in X and Y directions. According to $r = \sqrt{X^2 + Y^2}$, the value **r** corresponds to the vertical coordinate X, Y[cm] of the load curve, and the abscissa Z[cm] represents the distance from the gravity center of the load to the robot flange in Z direction. You can determine the working condition of the robot according to the statistical results. For example, if the load is 2.8kg, X = 6cm, Y = 8cm, Z = 5cm, and you can get r = 10cm. The steps for judgement are as follows:

- According to $r = \sqrt{X^2 + Y^2}$, calculate r = 10cm.
- Select the corresponding curve according to the weight of the load. As the load is 2.8kg, you need to find the curve of 3kg correspondingly.
- Determine a point according to the r and Z coordinates, and compare the positional relationship between the point and the 3kg curve to judge the working condition. If the point is below the curve, the model is proper, otherwise you need to select other models.




Figure 5.12 CR7 load curve

5.4 CR10 mechanical specifications

5.4.1 CR10 dimensions and working range

When selecting the installation position for the robot, you must consider the cylindrical space directly over and under the robot, and avoid moving the tool to the cylindrical space as much as possible. Because this will cause the joints to rotate too fast while the tool moves slowly, resulting in low working efficiency of the robot and difficult risk assessment.






Figure 5.13 CR10 dimensions and working space

5.4.2 CR10 base installation dimensions






Figure 5.14 CR10 base installation dimensions

5.4.3 CR10 end flange dimensions

The end flanges of CR series robot arms are all in the same size. The flange design conforms to ISO 9409-1.




Figure 5.15 End flange dimensions

User Guide



5.4.4 CR10 load curve

In the load curve, the coordinate origin is the center of the end flange, and X, Y represent the distance between the gravity center of load and the robot flange in X and Y directions. According to $r = \sqrt{X^2 + Y^2}$, the value **r** corresponds to the vertical coordinate X, Y[cm] of the load curve, and the abscissa Z[cm] represents the distance from the gravity center of the load to the robot flange in Z direction. You can determine the working condition of the robot according to the statistical results. For example, if the load is 3.8kg, X = 6cm, Y = 8cm, Z = 5cm, and you can get r = 10cm. The steps for judgement are as follows:

- According to $r = \sqrt{X^2 + Y^2}$, calculate r = 10cm.
- Select the corresponding curve according to the weight of the load. As the load is 3.8kg, you need to find the curve of 4kg correspondingly.
- Determine a point according to the r and Z coordinates, and compare the positional relationship between the point and the 4kg curve to judge the working condition. If the point is below the curve, the model is proper, otherwise you need to select other models.




Figure 5.16 CR10 load curve

5.5 CR12 mechanical specifications

5.5.1 CR12 dimensions and working range

When selecting the installation position for the robot, you must consider the cylindrical space directly over and under the robot, and avoid moving the tool to the cylindrical space as much as possible. Because this will cause the joints to rotate too fast while the tool moves slowly, resulting in low working efficiency of the robot and difficult risk assessment.






Figure 5.17 CR12 dimensions and working space

5.5.2 CR12 base installation dimensions






Figure 5.18 CR12 base installation dimensions

5.5.3 CR12 end flange dimensions

The end flanges of CR series robot arms are all in the same size. The flange design conforms to ISO 9409-1.




Figure 5.19 End flange dimensions



5.5.4 CR12 load curve

In the load curve, the coordinate origin is the center of the end flange, and X, Y represent the distance between the gravity center of load and the robot flange in X and Y directions. According to $r = \sqrt{X^2 + Y^2}$, the value **r** corresponds to the vertical coordinate X, Y[cm] of the load curve, and the abscissa Z[cm] represents the distance from the gravity center of the load to the robot flange in Z direction. You can determine the working condition of the robot according to the statistical results. For example, if the load is 3.8kg, X = 6cm, Y = 8cm, Z = 5cm, and you can get r = 10cm. The steps for judgement are as follows:

- According to $r = \sqrt{X^2 + Y^2}$, calculate r = 10cm.
- Select the corresponding curve according to the weight of the load. As the load is 3.8kg, you need to find the curve of 4kg correspondingly.
- Determine a point according to the r and Z coordinates, and compare the positional relationship between the point and the 4kg curve to judge the working condition. If the point is below the curve, the model is proper, otherwise you need to select other models.




Figure 5.20 CR12 load curve

5.6 CR16 mechanical specifications

5.6.1 CR16 dimensions and working space

When selecting the installation position for the robot, you must consider the cylindrical space directly over and under the robot, and avoid moving the tool to the cylindrical space as much as possible. Because this will cause the joints to rotate too fast while the tool moves slowly, resulting in low working efficiency of the robot and difficult risk assessment.






Figure 5.21 CR16 dimensions and working space

5.6.2 CR16 base installation dimensions






Figure 5.22 CR16 base installation dimensions

5.6.3 CR16 end flange dimensions

The end flanges of CR series robot arms are all in the same size. The flange design conforms to ISO 9409-1.




Figure 5.23 End flange dimensions



5.6.4 CR16 load curve

In the load curve, the coordinate origin is the center of the end flange, and X, Y represent the distance between the gravity center of load and the robot flange in X and Y directions. According to $r = \sqrt{X^2 + Y^2}$, the value **r** corresponds to the vertical coordinate X, Y[cm] of the load curve, and the abscissa Z[cm] represents the distance from the gravity center of the load to the robot flange in Z direction. You can determine the working condition of the robot according to the statistical results. For example, if the load is 3.8kg, X = 6cm, Y = 8cm, Z = 5cm, and you can get r = 10cm. The steps for judgement are as follows:

- According to $r = \sqrt{X^2 + Y^2}$, calculate r = 10cm.
- Select the corresponding curve according to the weight of the load. As the load is 3.8kg, you need to find the curve of 4kg correspondingly.
- Determine a point according to the r and Z coordinates, and compare the positional relationship between the point and the 4kg curve to judge the working condition. If the point is below the curve, the model is proper, otherwise you need to select other models.




Figure 5.24 CR16 load curve

5.7 Controller dimensions

The dimensions of CC162 controller are shown in Figure 5.25.






Figure 5.25 Controller dimensions



6. Electrical Features

6.1 Controller interface

6.1.1 Overview

The interfaces of the controller are shown in Figure 6.1.




Figure 6.1 Controller electrical interfaces

Table 6.1 Interface panel description

No.	Description	
1	USB interface	
	For connecting to WiFi module	
2	SmartPendant and emergency stop switch interface	
	For connecting to SmartPendant (optional) or emergency stop switch	
3	LAN interface (default address: 192.168.5.1)	
	For connecting to PC (Used for debugging), or other external network equipment of TCP/IP or Modbus TCP protocol	
4	General I/O interface	
	See 6.1.2 General I/O interface panel	
5	Power switch of controller	
	For powering on/off the controller	
6	Power interface	
	For accessing single-phase 1100/220V AC power supply	



No.	Description	
7	External DC 48V power supply reserved port	
	For accessing AGV to supply 48V DC power to the robot	
8	Safety I/O interface	
	See 6.1.6 Safety I/O interface for details	
9	Heavy-duty connector interface	
	For connecting to robot, powering robot and communication	

6.1.2 General I/O interface panel

The robot controller contains an I/O interface panel for connecting to external equipment, such as air pump, PLC, etc. The I/O interface panel provide 32 digital inputs, 16 digital outputs (multiplex with 16 digital inputs), 2 analog outputs, and 2 analog inputs and an incremental encoder input.




Figure 6.2 Controller I/O interface



Table 6.2 Pin definition

PIN	Name	Definition
1	DI1	Digital input 1
2	DI2	Digital input 2
3	DI3	Digital input 3
4	DI4	Digital input 4
5	DI5	Digital input 5
6	DI6	Digital input 6
7	DI7	Digital input 7
8	DI8	Digital input 8
9	I/O 0V	Ground for I/O interface
10	0V	Ground for internal DC24V power supply
11	I/O17	Digital input 17 /output 1
12	I/O18	Digital input 18 /output 2
13	I/O19	Digital input 19 /output 3
14	I/O20	Digital input 20/output 4
15	I/O21	Digital input 21/output 5
16	I/O22	Digital input 22/output 6
17	I/O23	Digital input 23/output 7
18	I/O24	Digital input 24/output 8
19	I/O 24V	Ground for I/O interface
20	24V	Ground for internal DC24V power supply
21	DI9	Digital input 9
22	DI10	Digital input 10
23	DI11	Digital input 11
24	DI12	Digital input 12
25	DI13	Digital input 13
26	DI14	Digital input 14
27	DI15	Digital input 15
28	DI16	Digital input 16



PIN	Name	Definition
29	I/O 0V	Ground for I/O interface
30	0V	Ground for internal DC24V power supply
31	I/O25	Digital input 25/output 9
32	I/O26	Digital input 26/output 10
33	I/O27	Digital input 27/output 11
34	I/O28	Digital input 28/output 12
35	I/O29	Digital input 29/output 13
36	I/O30	Digital input 30/output 14
37	I/O31	Digital input 31/output 15
38	I/O32	Digital input 32/output 16
39	I/O 24V	I / O interface DC 24V power input
40	24V	Internal DC 24V power output
41	I/O 0V	Ground for I/O interface
42	A-	Incremental Encoder ABZ Input
43	B-	
44	Z-	
50	A+	
51	B+	
52	Z+	
45	I/O 0V	Ground for I/O interface
46	AI 1	Analog input 1
47	I/O 0V	Ground for I/O interface
48	AO 1	Analog output 1
49	I/O 5V	Internal DC 5V power output
53	I/O 24V	I/O interface DC 24V power input
54	AI 2	Analog input 2
55	I/O 0V	Ground for I/O interface
56	AO 2	Analog output 2

6.1.3 **Digital I/O interface**



Digital I/O interfaces can be powered by internal 24V power supply, with total output current of 2A and 500mA maximum for each I/O output. When using the internal power supply, short-circuit 0V with I/O 0V or 24V with I/O 24V interfaces, as shown below.




Figure 6.3 I/O using internal power supply

You can connect an external power supply if larger total output current (maximum: 4A) is required, as shown below.




Figure 6.4 I/O connected to external power supply

The wiring of DI connected to a simple switch is shown below.






Figure 6.5 DI connected to PNP-type input

The wiring of DI connected to external DO is shown in Figure 6.6, which takes PNP-type DO without power supply as an example. If DO has its own power supply, you do not need to connect V+ cable.




Figure 6.6 DI connected to PNP-type input

The wiring of DO connected to external load is shown in Figure 6.7.




Figure 6.7 DO connected to external load

6.1.4 Analog I/O interface



The analog signal supports voltage (0~10V) or current (4~20mA) signal (default: voltage). If you need to adjust it to current signal, please contact Dobot technical support.

The wiring of AI interface connected to the tested object is shown in Figure 6.8.




Figure 6.8 Al connected to tested object

The wiring of AO interface connected to the external load is shown in Figure 6.8.




Figure 6.9 AO connected to external load

6.1.5 Encoder I/O interface

An encoder is a device that converts angular or linear displacement into electrical signals. Specifically, it converts displacement into periodic electrical signals and then converts electrical signals into count pluses. So the displacements can be measured by the number of pluses.

This section takes OMRON E6B2-CWZ1X as an example to describe how to connect it.

According to different color cables of the encoder, connect the 5V power cable to Pin49, 0V power cable to Pin41, and then connect each coded wiring in turn. If the ground wire is required, you can fix the cable shield on the controller using screws. There is no need to connect the ground wire unless in special circumstances (strong magnetic interference, etc.).

Table 6.3 Wiring color

Color	Description
Brown	I/O 5V
Blue	I/O 0V

Issue V1.2 (2023-06-08) User Guide Copyright © Yuejiang Technology Co., Ltd.



Color	Description
Black	A+
White	B+
Orange	Z+
Black and red	A-
White and red	В-
Orange and red	Z-

6.1.6 Safety I/O interface

The safety I/O includes 20 interfaces: SI1~SI10, SO1~SO10.

SI02/SI03/SI04/SI05/SI10 interfaces can be configured to user emergency stop input, protective stop input, protective stop reset input, reduction mode input and automatic running input through control software. The above interfaces can be configured randomly (single/dual) and are not configured by factory default.

You can configure the SO03/SO05 interfaces through software as the emergency stop output, running state output, non-stop output and reduction mode output interfaces. These interfaces can be configured randomly (single channel) and are not configured by factory default. SO02, SO04 and SO10 are high level by default and can be connected to security peripherals.

Emergency stop interface

Emergency stop I/O is an emergency stop interface for you to connect to external emergency stop devices.

By default, the emergency stop input is the normally closed signal input of high level. Low level triggers the robot to enter the emergency stop status.

If you configure SI02 and SI03 as emergency stop I/O, the wiring of connecting one or multiple emergency stop switches is shown below (SO02 and SO04 are 24V).






Figure 6.10 SI connected to an emergency stop switch




Figure 6.11 SI connected to multiple emergency stop switches

Protective stop interface

The protective stop interface is used for connecting external protective devices (such as safety gate, safety light curtains, etc.).

The protective stop input is the normally closed signal input of high power by default. Low level triggers the robot to enter protective stop state (pause state).

- When the protective stop reset interface is configured, the operation of the robot can be resumed only by restoring the protective stop input signal and triggering the protective stop reset input.
- When the protective stop reset interface is not configured, the operation of the robot can be resumed by restoring the protective stop input signal.

Protective stop reset interface

The protective stop reset interface is used to reset the protective stop state.

The default protective stop reset input is the normally open signal of high power, and rising edge triggers to reset the protective stop state.

If you configure SI04 and SI05 as protective stop input and SI10 as protective stop reset input, the wiring is shown below (SO02, SO04 and SO10 are 24V).






Figure 6.12 SI connected to protective stop device (with reset switch)

Reduction mode interface

Reduction mode interface is used to control the robot into reduction mode. In reduction mode, the motion parameters of the robot arm (joint speed, TCP speed) are limited within the range of the user-defined reduction mode.

The default input of reduction mode is the normally closed signal of high level, and low-level input triggers the robot to enter the reduction mode. If the high-level input is restored, the robot exits the reduction mode and enters the normal mode.




Figure 6.13 SI connected to reduction mode switch

Automatic operation confirmation interface

You need to confirm the automatic operation interface before the robot enters the automatic operation mode. The default automatic operation input is the normally open signal of high power, and rising edge triggers the robot to start the automatic mode confirmation.

If you configure SI04 and SI05 as automatic operation confirmation input, the wiring of connecting automatic operation confirmation switch is shown below (SO02 and SO04 are 24V).

Emergency stop state output interface

The emergency stop state output interface is used to confirm whether the robot enters the emergency stop state. In emergency stop state, the output voltage is low level, and in non-emergency stop state, the output voltage is high level.

If you configure SO03 as emergency stop state output, the wiring of connecting external load is shown below. The other end of the load can be connected to any 0V interface on the general I/O

Issue V1.2 (2023-06-08)

User Guide

Copyright © Yuejiang Technology Co., Ltd.



interface panel. The figure below only shows an example.




Figure 6.14 SO connected to external load

Running state output interface

The running state output interface is used to confirm whether the robot is in running state. The output voltage is low level in the running state, and high level in the non-running state.

Non-stop state output interface

The non-stop state output interface is used to check whether the script is running. The output voltage is low level when the script is running, and high level when the script is not running.

Reduction mode state interface

The reduction mode state output interface is used to check whether the robot enters the reduction mode. The output voltage is low level when the robot is in the reduction mode, and high level when the robot is in the normal mode.

■NOTE

If the firmware version of the controller is lower than 3.5.4, the level definition of security output is opposite.


6.2 Robot interface



6.2.1 Heavy-duty interface

The heavy-duty connector of robot base is connected to the controller by overloading lines. It provides power supply and control signal for the robot. The pin distribution is shown below.

Power interface: Pin4 Pin3 Pin2 Pin1




Communication interface: Pin8~Pin1

Pin		Name	Description
Power interface	Pin1	DC48V	DC48V +
	Pin2	DC48V	DC48V +
	Pin3	GND	DC48V -
	Pin4	GND	DC48V -
Communication interface	Pin1	TX+	Transmit data +
	Pin2	TX-	Transmit data -
	Pin3	RX+	Receive data +
	Pin6	RX-	Receive data -

6.2.2 Tool I/O interface


The end interface is an aerial plug located on the side of the end flange. The socket pins are distributed and defined as follows.





Pin	Name	Description
1	485A	485A
2	485B	485B
3	DI_2	Digital input 2
4	DI_1	Digital input 1
5	24V	24V output
6	DO_2	Digital output 2
7	DO_1	Digital output 1
8	GND	GND

The cable used in the tool I/O is the cable specified by Dobot (model: Lutronic FP-222460). The pin distribution and cable definition of the plug are shown as follows.



Pin	Wire color	Description	
1	white	485A or analog input 1	
2	brown	485B or analog input 2	
3	green	Digital input 2	
4	yellow	Digital input 1	
5	grey 24V output		
6	pink	Digital output 2	
7	blue	Digital output 1	
8	red	GND	

Digital input/output:

The maximum current of 24V output of tool I/O is 2A (no more than 1s continuously), and the digital input is PNP type.

Issue V1.2 (2023-06-08)

User Guide

Copyright © Yuejiang Technology Co., Ltd.



When using external simple switching circuit as the DI input source, the wiring is shown in Figure 6.15.




Figure 6.15 End DI wiring (simple switch)

When using the DO terminal of an external device as the DI input source, the wiring is shown in Figure 6.16, which takes a PNP-type DO without power supply as an example. If the DO has its own power supply, you do not need to connect the 24V cable.




Figure 6.16 End DI wiring (PNP type DO)

The digital output of the tool I/O is NPN type, with the single output current no more than 400mA and the total output current no more than 400mA. The wiring is shown as follows.




Figure 6.17 End DO wiring

Analog input

The wiring of analog I/O connected to the tested object is shown in Figure 6.18.






Figure 6.18 End Al wiring



7. Installation and Use

7.1 Installation environment

To maintain the performance of the controller and robot arm and ensure safe use, please place the controller and robot in an environment with the following conditions.



Please make sure that the installation environment meets the following conditions to avoid damage.

- Install indoors with good ventilation.
- Keep away from excessive vibration and shock.
- Keep away from direct sunlight.
- Keep away from dust, oily smoke, salinity, metal powder, corrosive gases, and other contaminants.
- Do not use in a closed environment. A closed environment may cause high temperature of the controller and shorten its service life.
- Keep away from flammable.
- Keep away from cutting and grinding fluids
- Keep away from sources of electromagnetic interference, such as large transformer, large electromagnetic contactor, electric welding machine, etc.
- When the robot is transported, ensure that the robot is stable and kept in proper place.
- When the robot is hoisted, be sure to take appropriate measures to locate the moving parts so as not to cause accidental movement and harm during hoisting and transportation.
- When moving the robot from the packing box to the mounting position, hold the robot until all bolts on the robot base are fastened.
- When the robot is installed, take corresponding measures to locate it. Be sure to use 4 hex bolts M6 (CR3)/M8 (Other models) (ISO898-1: 2013, property class: 12.9) with 20N•m torque to fix and tighten the robot base.
- When the robot is installed on the wall or upside down, be sure to take the anti-fall measures of the robot base.
- When the robot is installed, fix the robot on a sufficiently strong base, which needs to be able to fully withstand the reaction force of the robot acceleration and deceleration and the static weight of the robot and the workpiece.

7.2 Unpacking

When unpacking, please check the attached shipping list to ensure that all contents are included. If there is anything missing, please contact your supplier.



7.3 Robot installation

7.3.1 Robot arm installation

CR robot arm supports 360° installation at any angle. Figure 7.1 shows several typical installation postures.



Figure 7.1 CR robot installation posture

The installation platform of the robot arm should be stable enough to withstand at least 10 times the maximum torque of the J1 joint, and at least 5 times the weight of the robot arm.

If the robot arm is installed on a linear axis or a moving platform, the acceleration of the platform should be low, and high acceleration may trigger the robotic arm's collision detection mechanism and cause the robotic arm to stop.

Position the mounting holes on the installation platform according to the installation size of the robot base. Fix the robot arm base on the surface using bolts (4 M6 bolts for CR3, and 4 M8 bolts for other models). You can refer to 5 Mechanical Specifications for the specific dimensions of the robot base.




Figure 7.2 Base installation

7.3.2 Controller installation

Place the controller on a stable platform outside the working range of the robot arm, and reserve enough space for wiring and operation. Please leave at least 200 mm gap on the left and right sides and keep the vent unblocked to ensure enough space for heat dissipation. Place the control cabinet on a solid and flat plane outside the working space of the robotic arm, and reserve enough cable wiring space and operation space. A space of 200mm should be reserved on the left and right sides, and the trend will not be blocked to ensure sufficient heat dissipation space.






Figure 7.3 Controller installation space requirement

7.3.3 End tool installation

The end flange of the robot arm has four M6 threaded holes, which can fix the tool to the end of the robot arm. In order to accurately adjust the position of the tool, you can also use the reserved $\Phi6$ positioning hole. The end flanges of CR series robot arms are in the same size. For detailed dimensions, refer to 5 Mechanical Specifications.

7.4 Wiring




Figure 7.4 Wiring diagram

- 1. Connect the controller to robot arm through a heavy-duty cable. When you plug the heavy-duty connector into the heavy-duty socket, fix the buckle of the heavy-duty connector.
- 2. Plug the emergency stop switch cable to the emergency stop switch interface. When connecting, align the red point on the connector with the red point on the interface.
- 3. Plug the wireless receiver into the USB interface.

Issue V1.2 (2023-06-08)

User Guide

Copyright © Yuejiang Technology Co., Ltd.



4. Plug one end of the power cable into the power interface of the controller, and the other end into main power socket.




Figure 7.5 Controller wiring

⚠NOTICE

- Set the specifications and installation method of external cables in compliance with local power distribution laws and regulations.
- Do not remove the controller by yourself, otherwise it may cause electricity leakage.
- Make sure the device is grounded.
- Do not bend the cable excessively, otherwise it may cause poor contact or cable breakage.
- Make sure the power outlet for the control system is disconnected when connecting an external device, otherwise it may cause an electric shock or device failure.
- Use supporting cables to protect device and personal safety.
- After wiring, ensure that there are no fallen screws or exposed cables in the device.
- Do not plug or remove the power cable or communication cable when the device is running normally.
- Power on the device only after connecting all the cables required.
- Ensure that the cables are connected correctly, otherwise, it may cause fault in internal modules or external devices.
- Before connecting, check whether there is breakage in the insulation and shield of the external cables.

7.5 **Debugging**

After turning on the external power supply, press the switch above the power interface to "|", and then short press the circular button in front of the controller. When the indicator lights at the end of the robot arm and on the controller turn blue, you can connect the robot arm, enable it and jog it for debugging through the operation terminal.



For specific operations, refer to *DobotStudio Pro User Guide* (for PC) or *Dobot CRStudio User Guide* (for App).



8. Maintenance

Maintenance and repairing must be performed in compliance with all safety instructions in this manual.

The purpose of maintenance and repairing is to ensure that the system is kept operational, or to return the system to an operational state in the event of a fault. Repairing includes troubleshooting in addition to the actual repair itself.

Repairing must be performed by an authorized system integrator or Dobot staff.

Robots or parts returned to Dobot should be as the following instructions.

- Remove all parts that do not belong to Dobot.
- Before returning to Dobot, please make a backup copy of the files. Dobot will not be responsible for the loss of programs, data or files stored in robot.
- The robot should move to the package point before returning to Dobot.

8.1 Safety instructions

The following safety procedures and warnings must be observed during the operation of the robot or controller:

- Replace faulty components using new components with the same model or equivalent components approved by Dobot.
- Reactivate all deactivated safety measures immediately after the repairing is completed.
- Record all repairs and save them in the technical document with the robot system.
- Remove the main input cables from the back of the controller to ensure that it is completely unpowered. Cut off any other power source connected to the robot or controller. Take necessary precautions to prevent other people from powering on the system during the repair period.
- Observe ESD regulations during the disassembly of the parts of the robot arm or controller.
- Avoid disassembling the power supply inside the controller. High voltage may remain inside the power supply for several hours after the controller has been powered off.
- Prevent water and dust from entering the robot arm or controller.

8.2 Robot maintenance

In order for the robot to maintain high performance for a long time, a maintenance inspection must be carried out. The personnel in charge of the maintenance must prepare a maintenance plan and carry out the maintenance. The maintenance items are shown below.

Table 8.1 Check items

Period	Maintenance	Maintenance essential
Issue V1.2 (2023-06-08)	User Guid	e Copyright © Yuejiang Technology Co., Ltd.



Daily	3 months	6 months	item	
√			Robot clean	Wipe off dirt, dust, cutting residue on the body with water or 10% alcohol
		√	Joint bolts	Check the torque of joint bolts based on the specified tightening torque table (Push aside the rubber to check)
	√		Tool mounting bolts	Check the torque based on the specified tightening torque table
√			Motor	Confirm abnormal heating or sound
√			Brake	Check whether the robot arm or end-effector will fall when the servo is powered off
	√		Reducer	Check abnormal vibration, noise, and oil leakage

The bolt tightening torque is shown in Table 8.2.

Table 8.2 Bolt tightening torque

Bolt size	Outer hexagonal bolt (joint)	Inner hexagonal bolt (12.9)	Hexagonal bolt (rear cover)
3 mm / 0.118 in	2 Nm	2.4 Nm	0.7 Nm
4 mm / 0.157 in	4 Nm	4.5 Nm	-
5 mm / 0.197 in	7.5 Nm	9 Nm	-
6 mm / 0.236 in	15 Nm	18 Nm	-
8 mm / 0.32 in	-	37 Nm	-

The tightening torques vary depending on the type of base metal or bolt. When it is not specified, please contact Dobot technical engineer.

In addition, maintenance is required every 20,000 hours of operation time or every 4 years (select the shorter of the two periods for maintenance). If you are not clear about the maintenance processes, please contact Dobot technical engineer.



9. Certification

Collaborative robot certification

产品认证证书

证书编号: TILVA202127001006



产品名称: DOBOT CR3、DOBOT CR5、DOBOT CR10、

DOBOT CR16

型号: DT-CR-6R030-001、DT-CR-6R050-001、DT-CR-6R100-001、

DT-CR-6R160-00I

规格参数: 额定电压/频率: AC 100V~240V/50\60Hz

申请人: 深圳市越疆科技有限公司

地址: 深圳市南山区桃源街道福光社区留仙大道 3370 号南山智园

崇文园区 2 号楼 1003

制造商: 深圳市越疆科技有限公司

地址: 深圳市南山区桃源街道福光社区留仙大道 3370 号南山智园

崇文园区 2 号楼 1003

生产厂: 深圳市京泉华智能电气有限公司

地址: 深圳市龙岗区坪地街道坪桥路 10 号京泉华科技产业园

产品标准: GB 11291.1-2011、GB/T 5226.1-2019、GB/T 15706-2012、

GB 17799.4-2012、GB/T 17799.2-2003

认证模式: 产品型式试验+初次工厂检查+获证后监督

上述产品符合产品认证实施规则 TILVA-27-001:2016 的要求,特发此证。

发证日期: 2021-06-18

有效期至: 2026-06-1

变更日期: /

证书有效性依据发证机构的定期监督获得保持。

批准人:



1/1





中国上海普陀区武宁路 505 号 200063 http://www.tilva.com



Robot reliability certification



证书编号: SRI-A-21024

国家机器人检测与评定中心(总部) 上海市机器人研发与转化功能型平台

可靠性证书

委 托 方 名 称: 深圳市越疆科技有限公司

委 托 方 地 址: 深圳市南山区留仙大道南山智园崇文园区2号楼1003室

制造厂名称: 深圳市越疆科技有限公司

制造厂地址: 深圳市南山区留仙大道南山智园崇文园区2号楼1003室

产品名称: 越疆CR5协作机器人

型 号/版 本: DT-CR-6R050-001

测 试 依 据: GB/T 39590.1-2020《机器人可靠性第1部分: 通用导则》

GB/T 12642-2013 《工业机器人 性能规范及其试验方法》

T/CEEIA 558-2021 《工业机器人可靠性测试与评定》

经测试评定,越疆CR5协作机器人平均无故障时间(MTBF)通过 30000 小时,现予认定,特发此证。

发证日期: 2022-06-24


国家机器人检测与评定中心 (总部) 上海市机器人研发与转化功能型平台

有效期至: 2024-06-23

上海机器人产业技术研究院有限公司



Functional safety certification









CE-MD certificate





CE-LVD certificate



VERIFICATION OF COMPLIANCE

No.: LVD SZFS2109000032BA

Applicant: Shenzhen Yuejiang Technology Co., Ltd.

Room 1003, Building 2, Chongwen Park, Nanshan iPark, No.3370, Liuxian Blvd, Fuguang Community, Taoyuan Street,

Nanshan District, Shenzhen, Guangdong, China

Manufacturer: Same as applicant

Product Name: CR-Series Collaborative Robot Safety System

DT-CR-6R030-00I; DT-CR-6R03S-00I; DT-CR-6R030-01I; DT-CR-6R03S-01I; DT-CR-6R05S-00I; DT-CR-6R05S-00I; Model No :

DT-CR-6R070-00I; DT-CR-6R07S-00I; DT-CR-6R100-00I; DT-CR-6R10S-00i; DT-CR-6R120-00i; DT-CR-6R12S-00i; DT-CR-6R160-00i; DT-CR-6R16S-00i.

Protection against Electric Shock: Class I

Sufficient samples of the product have been tested and found to be in conformity with

Test Standard: EN 60204-1:2018 Test Report Number(s): SZFS210910003201

This Verification of Compliance has been granted to the applicant based on the results of tests, performed by Laboratory of SGS-CSTC Standards Technical Services Co., Ltd. on sample of the above-mentioned product in accordance with the provisions of the relevant harmonized standards under the Low Voltage Directive 2014/35/EU. The CE marking as shown below can be affixed, under the responsibility of the manufacturer, after completion of an EC Declaration of Conformity and compliance with all relevant EC Directives. The affixing of the CE marking presumes in addition that the conditions in annexes III and IV of the Directive are fulfil

Rocky War

Laboratory T SGS-CSTC

2021-10-20

Copyright of this verification is owned by SGS-CSTC Standards Technical Services Co., Ltd. and may not be reproduced other than in full and with the prior approval of the General Manager. This verification is subjected to the governance of the General Conditions of Services, printed overleaf.

Member of SGS Group (Société Générale de Surveillance)

Safety-VOC-F005 Rev01/Effective Date :2020-12-11



CE-RoHS certificate





NRTL certificate

CERTIFICATE OF COMPLIANCE

SGSNA/21/SH/00207 Certificate Number:

800864 Contract Number:

Certificate Project Number: SH-CERT210401097

Certified Product: DOBOT CR3, DOBOT CR5, DOBOT CR10, DOBOT CR16, DOBOT CC162

DOBOT Trademarks:

Model(s): DT-CR-6R030-00I, DT-CR-6R050-00I, DT-CR-6R100-00I, DT-CR-6R160-00I

(Manipulator models),

Technical Data:

DT-CR-6R030-001 (Electrical cabinet model)
DT-CR-6R030-001: Input 48 VDC; FLA 4.4 A;
DT-CR-6R050-001: Input 48 VDC; FLA 6.3 A;
DT-CR-6R100-001: Input 48 VDC; FLA 9.4 A;
DT-CR-6R160-001: Input 48 VDC; FLA 8.4 A;

DT-CR-CC162-001: Input: 100-240 V 50/60 Hz Single phase; SCCR: 5 kA;

Output: 48 VDC.

Output: 48 VDC.
DOBOT CR3: Payload 3 kg; Max. reach 620 mm;
DOBOT CR5: Payload 5 kg; Max. reach 900 mm;
DOBOT CR10: Payload 10 kg; Max. reach 1300 mm;
DOBOT CR16: Payload 16 kg; Max. reach 1000 mm;

Certificate Holder:

Shenzhen Yuejiang Technology Co., Ltd.
Room 1003, Building 2, Chongwen Park, Nanshan iPark, No.3370, Liuxian Blvd,
Fuguang Community, Taoyuan Street, Nanshan District, Shenzhen City, 518071,

This certificate supercedes previous certificates issued with the same certificate number. Certification is valid when products are indicated on the SGS directory of certified products at www.gos.com or using the GR code below. The product is certified according to ISO/IEC Guide 17067, Conformity assessment - Fundamentals of product certification, System 3, and in accordance with:

ANSI/UL 1740, 4 Ed., Rev. June 20, 2019 CAN/CSA C22.2 No. 14-18

NFPA 79, 2018 Edition, 2018

Authorized by:

Jason Wei Certifier

Effective date: 30 July 2021

the company under its General Conditions for subble at https://www.sgs.com/entherm-and-to the limitations of liability defined therein and in mentioned which findings are reflected in this idention, lorgery or fesification of the content or is unlawful and offenders may be prosecuted to

Certification Body

Consumer and Retail Services, a division of SGS North Americ 620 Old Peachtree Road, Ste. 100, Suwanee, GA 30024, USA t +1 770 570 1800 f +1 770 277 1240 www.sgs.com



KCs certificate




자율안전확인 신고증명서

CENTER OF	사업장명	Shenzhen Yuejiang echnology Co.,Ltd	T 사업장관리번호	2021E220040
신청인	사업자등록번호	021E220040	대표자 성명	Lui Peichao
	소재지	E Room 1800, Buildings, Chang one Park Many	over that No III States Mr. Regions Community, See	over Sent, Natha Barut, Stender China
자율안전인	증대상 기계 : 기	구명	산업용로봇	
형식(규격)	DT	-CR-6R050-00I	용량(등급)	6 axis
자율안전확	인번호 💍	21-A	H2EQ-01042	
제조자	Ш	Shenzhen Yuejiang Technology Co.,Ltd.		
소재지	0 Brown to	() Room 1989, Beikling Z., Changuren Perk, Natedfein Bark, No. 2870, Levilan Blief, Fuguang Continue Nr., Targuan Screet, NatioNer Dattict, Sheroften China		

「산업안전보건법」 제89조제1항 및 같은 법 시행규칙 제120조제3항에 따라 자율안전확인 신고증명서를 발급합니다.

2021년 06월 10일













RCM certificate



Global Access Certification Australia Pty. Ltd. 960 Waverley Road, Wheelers Hill, Victoria 3150, Australia

Proof of RCM Compliance

Certificate No.: RCMP21261 001

Certificate holder: Shenzhen Yuejiang Technology Co., Ltd.

Room 1003, Building 2, Chongwen Park, Nanshan iPark, No. 3370, Liuxian Blvd, Fuguang Community, Taoyuan Street, Nanshan District, Shenzhen,

Guangdong, China

Product Description: Collaborative Robot (DOBOT CR3/ DOBOT CR5/ DOBOT CR10/

DOBOT CR16)

Brand Name: DOBOT

Model Number: DT-CR-6R030-00I, DT-CR-6R050-00I, DT-CR-6R100-00I, DT-CR-6R160-00I

Electrical Ratings: 48Vdc for Manipulator; 100-240Vac, 650W for controller

GACA approves that this Electrical Article as described above meets the requirements of the standard/regulation(s) listed below:

Standard/regulation(s) Complies with

EN 301 489-1 V2.2.3, EN 301 489-17 V3.2.4, EN 55032: 2015,

EN IEC 61000-6-4: 2019, EN IEC 61000-6-2: 2019, EN 300 328 V2.2.2, ACMA mandated

(Test report: SZEM210200212501, SZEM210200212502, SZEM210200212503)

IEC 60204-1: 2005+A1: 2008, EN ISO 10218-1: 2011 (Test report: SZES200110054701, SZES200100054701) Electrical Safety

EESS-National

Above models is registered as level 1 product on Equipment Database

Registration

https://equipment.erac.gov.au/Registration/EquipmentSearch.aspx?atn=public

Date of Registered: 10 May 2021 Date of Expiry: 20 September 2025

On behalf of GACA





10. Warranty

10.1 Product warranty

Without prejudice to any claim agreement that the user (customer) may reach with the distributor or retailer, the manufacturer shall guarantee the quality of the products to the customer in accordance with the terms and conditions below:

If defects caused by manufacturing and/or improper material occur in a new device and its components within 12 months (15 months at most if the shipping time is included) after the device is put into use, Dobot shall provide the necessary spare part, and the user (customer) shall offer personnel to replace the spare part, using another part that represents the latest technology level to replace or repairing the related part.

If the device defects are caused by improper handling and/or failure to follow the relevant information set out in the User Guide, the warranty is invalid.

This warranty does not apply to or extend to maintenance (e.g. installation, configuration, software download) performed by the authorized distributer or customer.

The user (customer) must provide the purchase receipt and the purchase date as valid evidence for the warranty. Claims under this warranty must be made within two months of the apparent failure to perform the product warranty.

The ownership of the equipment or components that are replaced or returned to Dobot shall remain with Dobot. Any other claims arising from or related to the equipment are not covered by this warranty.

Any items in this product warranty do not intend to limit or exclude the legal rights of the customer or to limit or exclude the liability of the manufacturer for the personnel casualty resulting from its negligence. The duration of this product warranty shall not be extended due to the services provided under the product warranty terms. Under the principle of not violating the warranty, Dobot reserves the right to charge customers for the replacement or maintenance. The foregoing does not imply a change in the burden of proof to the detriment of the client. If there are defects on the equipment, Dobot shall not be liable for any damage or loss arising therefrom, including but not limited to loss of production or damage to other production equipment.

10.2 Disclaimer

Dobot is committed to improve the reliability and performance of its products, and as such reserves the right to upgrade products without prior notice. Dobot strives to ensure the contents of the User Guide are precise and reliable, but takes no responsibility for any errors or missing information.



Appendix Technical Specifications

Appendix A Robot technical specifications

Product		DOBOT CR3	DOBOT CR5	DOBOT CR7		
Weight		16.5kg (36.4lb)	25kg (55.1lb)	24.5kg (54lb)		
Maximum load		3kg (6.6lb)	5kg (11lb)	7kg (15.4lb)		
Working ra	dius	620mm (24.4in)	900mm (35.4in)	800mm (31.5in)		
Full-load co	urrent	4.4A	6.3A	8.2A		
Nominal voltage		DC 48V				
Maximum v	working	2m/s (78.7in/s)	3m/s (118.1in/s)	3m/s (118.1in/s)		
Joint	J1		±360°			
working range	J2		±360°			
range	J3	±155°	±160°	±160°		
	J4	±360°				
	J5	±360°				
	J6	±360°				
Maximum	J1	180°/s	180°/s	180°/s		
joint speed	J2	180°/s	180°/s	180°/s		
Specu	J3	180°/s				
	J4	180°/s				
	J5	180°/s				
	J6	180°/s				
Tool I/O	DI	2				
	DO	2				
	Al	2				
RS485		ModBus_RTU (AI multiplexing)				
Repeatabil	ity	±0.02mm	±0.02mm	±0.02mm		
IP rating		IP54				
Temperatu	re range	0°C~45°C				
Typical pov	wer	120W	150W	150W		



consumption				
Maximum power consumption	170W	300W	300W	
Material		Aluminum alloy, ABS		
Operating altitude range	≤1000m			
Installation mode	Normal mounting,	lifting, side mounting and mo	ounting at any angle	
Safety standard	Normal mounting, lifting, side mounting and mounting at any angle UL1740: 2018-Standard for Safety: Robot and Robotic Equipment; CSA Z434-14 (R2019) Industrial robots and robot systems NFPA 79:2018 Electrical Standard for Industrial Machinery EN ISO 10218-1:2011 Steel wire and wire products. General. Test methods EN 60204-1:2018 Safety of machinery. Electrical equipment of machines. General requirements; IEC 60204-1:2016 Safety of machinery. Electrical equipment of machines. General requirements; EN ISO 12100:2010 Safety of machinery. General principles for design. Risk assessment and risk reduction; ISO/TS 15066:2016 Robots and robotic devices-Collaborative robots; ISO 13849-1:2015 Safety of machinery-Safety-related parts of control systems -Part 1: General principles for design			
EMC Standard	EN IEC 61000-6-2:2019-Generic Standards-Immunity for industrial environments; EN IEC 61000-6-4:2019-Generic standards - Emission standard for industrial environments; EN IEC 61000-6-7:2014 Electromagnetic compatibility (EMC). Generic standards. Immunity requirements for equipment intended to perform functions in a safety-related system (functional safety) in industrial locations			

Product		DOBOT CR10	DOBOT CR12	DOBOT CR16
Weight		40kg (88.2lb)	39.5kg (87.1lb)	40kg (88.2lb)
Maximum I	oad	10kg (22lb)	12kg (26.5lb)	16kg (35.3lb)
Working ra	dius	1300mm (51.2in)	1200mm (47.2in)	1000mm (39.4in)
Full-load current		9.4A	9.4A	8.4A
Nominal vo	ltage	DC 48V		
Maximum speed	working	4m/s (157.5in/s)	4m/s (157.5in/s)	3m/s (118.1in/s)
Joint	J1	±360°		
working	J2	$\pm 360^{\circ}$		



range	J3		±160°				
	J4	±360°					
	J5		±360°				
J6			±360°				
Maximum	J1	120°/s					
joint	J2	120°/s					
speed	J3	180°/s					
	J4		180°/s				
	J5		180°/s				
	J6		180°/s				
Tool I/O	DI		2				
	DO		2				
	Al		2				
	RS485	ModBus_RTU ((AI multiplexing))					
Repeatabili	ity	± 0.03 mm					
IP rating		IP54					
Temperatu	re	0°C~45°C					
Typical Power Supply		350W					
Maximum consumption	power	450W	450W	400W			
Material		Aluminum alloy, ABS					
Operating altitude range		≤1000m					
Installation	mode	Normal mounting, lifting, side mounting and mounting at any angle					
Safety stan	ndard	UL1740: 2018-Standard for Safety: Robot and Robotic Equipment; CSA Z434-14					
		(R2019) Industrial robots and robot systems					
		NFPA 79:2018 Electrical Standard for Industrial Machinery					
		EN ISO 10218-1:2011 Steel wire and wire products. General. Test methods					
		EN 60204-1:2018 Safety of machinery. Electrical equipment of machines. General					
		requirements;					
		IEC 60204-1:2016 Safety of machinery. Electrical equipment of machines.					
		General requirements;					



	EN ISO 12100:2010 Safety of machinery. General principles for design. Risk
	assessment and risk reduction;
	ISO/TS 15066:2016 Robots and robotic devices-Collaborative robots;
	ISO 13849-1:2015 Safety of machinery-Safety-related parts of control systems -Part 1:
	General principles for design
EMC Standard	EN IEC 61000-6-2:2019-Generic Standards-Immunity for industrial environments;
	EN IEC 61000-6-4:2019-Generic standards - Emission standard for industrial
	environments;
	EN IEC 61000-6-7:2014 Electromagnetic compatibility (EMC). Generic standards.
	Immunity requirements for equipment intended to perform functions in a safety-related
	system (functional safety) in industrial locations



Appendix B Controller technical specifications

Product Name	DOBOT CC162	
Product Model	DT-CR-6R162-00I	
Axis Control	6 axes	
Input Power	1 PHASE	
	100V~240V AC, 50/60 Hz	
Output Power	48V DC, MAX nominal current: 12.5A, maximum current: 20A	
I/O Interface	16 digital inputs	
	16 digital inputs/outputs (multiplexing)	
	• 2 analog outputs (voltage: 0V~10V, current: 4mA~20mA)	
	• 2 analog inputs (voltage: 0V~10V, current: 4mA~20mA)	
	1 incremental encoder ABZ input	
Teaching Method	PC software, App (iOS/Android)	
Programming Language	Script (Lua)/Blockly programming	
Installation Method	Floor mounting	
Environment	Temperature: 0°C~45°C	
	Humidity: ≤95%, no condensation	
Protection Grade	IP20	
Cooling Method	Forced air cooling	
Safety Function	Emergency stop, external safety I/O interface reserved	
Safety Standard	UL1740: 2018-Standard for Safety: Robot and Robotic Equipment;	
	CSA Z434-14 (R2019) Industrial robots and robot systems	
	NFPA 79:2018 Electrical Standard for Industrial Machinery	
	EN ISO 10218-1:2011 Steel wire and wire products. General. Test methods	
	EN 60204-1:2018 Safety of machinery. Electrical equipment of machines.	
	General requirements;	
	IEC 60204-1:2016 Safety of machinery. Electrical equipment of machines.	
	General requirements;	
	EN ISO 12100:2010 Safety of machinery. General principles for design. Risk	
	assessment and risk reduction;	
	ISO/TS 15066:2016 Robots and robotic devices-Collaborative robots;	
	ISO 13849-1:2015 Safety of machinery-Safety-related parts of control systems -Part 1:	
	General principles for design	



EMC Standard	EN IEC 61000-6-2:2019-Generic Standards-Immunity for industrial environments;	
	EN IEC 61000-6-4:2019-Generic standards - Emission standard for industrial	
	environments;	
	EN IEC 61000-6-7:2014 Electromagnetic compatibility (EMC). Generic standards.	
	Immunity requirements for equipment intended to perform functions in a safety-related	
	system (functional safety) in industrial locations	



Appendix C I/O simple circuit and specifications

Digital input




Figure C.1 Digital input simple internal circuit

Table C.1 Digital input technical specifications

Item	Specification
Input channel	16 channels
Connection method	Tube type pre-insulated terminal E0510
Input type	Optical coupling isolation input
Input voltage (DC)	24V±10%

Multiplexed digital input/output interface




Figure C.2 Multiplexed digital input/output simple circuit



Table C.2 Multiplexed digital input/output technical specifications

Item	Specification
Output channel	16 channels
Connection method	Tube type pre-insulated terminal E0510
Output type	High-side switch
Power supply (DC)	24V±10%
Load current of single channel	500mA
Output current	2A
Isolation method	Digital isolation

Analog input

The type of input can be adjusted through a DIP switch. "U" means voltage input, "I" means current input (default: voltage). The DIP switch is located inside the controller. If you need to adjust it, please contact Dobot technical support.




Figure C.3 Analog input simple circuit

Figure C.3 Analog input type

Analog input type	Range
Current input	Current: 4mA~20 mA
Voltage input	Voltage: ±10V

Analog output

The type of output can be adjusted through a DIP switch. "U" means voltage output, and "I" means current output (default: voltage).

The DIP switch is located inside the controller. If you need to adjust it, please contact Dobot technical support.

Issue V1.2 (2023-06-08)

User Guide






Figure C.4 Analog output simple circuit

Table C.4 DIP switch status and analog output type

DIP switch status	Analog output type	Range
ON	Current output	Current: 4mA~20mA
OFF	Voltage output	Voltage: 0V~10V